

ACLS – The Life Support Rack – for Accommodation on the ISS

Dr. Carsten Matthias

Deutscher Luft- und Raumfahrtkongress 2018

4 – 6 September 2018 - Friedrichshafen



AIRBUS

©2018

ACLS Overview

- **ACLS** is a technology demonstrator and stands for “**Advanced Closed Loop System**”. It is a Life Support Rack originally designed for a **crew of 3** and for up-to 10 years of on-orbit operations.
- **ACLS** will be **launched in Sept. 2018 with HTV-7** from Tanegashima Space Center, **Japan**.
- **ACLS** will be **installed in the US Lab Module** of the ISS on position (LAB1) P1.
- About 4 – 6 weeks of in-orbit commissioning are considered. Afterwards **ACLS will provide services** (CO₂ removal, O₂ generation and water production) to the ISS.



Fig. 1: ACLS – The Life Support Rack



ACLS Objectives

- ACLS is integrated in an ISPR Rack and covers the following life support functions:
 - removal of carbon dioxide from the ISS atmosphere via a regenerative adsorption & desorption process
 - Technology based-on a Solid Amine resin
 - supply of breathable oxygen via electrolysis of water
 - Technology based-on a Fixed Alkaline Electrolyser
 - catalytic conversion of carbon dioxide with hydrogen to water and methane
 - Technology uses a Two Stage Sabatier Reactor Design



Fig. 2: ACLS Integration in HTV-7;
day 17/04/18

ACLS Main Characteristics

- Sized for crew of 3:
 - Scrubs min. 3 kg/day CO₂ (at 3 mmHg or 0,4vol% CO₂ in cabin air)
 - Produces ≈ 2.5 kg/day O₂
 - Produces ≈ 1.2 kg/day water
- Needs ≈ 3 kg/day potable water for O₂ production from the POTABLE WATER BUS.
- Needs waste water for steam regeneration of the CO₂ adsorber resin from the WASTE WATER BUS.
- ACLS uses MTL (MODERATE TEMPERATURE COOLING LOOP) for thermal control.
- ACLS Power Consumption in full SYS-OPS: 2.1 kW average, < 4.5 kW peak.



Fig. 3: ACLS in HTV-7



ACLS Design Description

Photobioreactor CO2 I/F

CCA S/S (Drw#1, #2)

Function: removal of carbon dioxide from the spacecraft atmosphere

CRA S/S (Drw#4)

Function: production of water from CO₂ and H₂ (service provision) to decrease water up-load to ISS

Air outlet to cabin

CCA S/S (Drw#3)

Function: air and water management

UIP

Air inlet from cabin

Tool Compartment

Avionics (Drw#8)

OGA S/S (Drw#6)

Function: supply of breathable oxygen via electrolysis

O2 injection port to cabin

Avionics (Drw#7)

Feed Water Supply with ACTEX cartridge

Waste Water Supply






Fig. 4: ACLS Front view




CCA S/S: Carbon Dioxide Concentration Subsystem consists of Drw#1, #2, #3



Drawer#1 with CO₂ Management and Avionics



Drawer#2 with CO₂ adsorber beds



Drawer#3 with Air and water Management

CCA S/S: CCA Adsorber Section (Drw#2)

- CCA fan draws cabin air through adsorber beds
- CO₂ adsorption on Astrine™ resin (solid amine; very good efficiency at low CO₂ levels; nominal working point: 4 hPa CO₂ air inlet concentration)
- CO₂ desorption at 105°C steam (3-bed system); desorption of CO₂ overlapping in order to provide smooth CO₂ flow to CRA; no CO₂ buffer tank needed.
- CO₂ Desorption at ambient pressure, no compressor needed
- CO₂ drying stage integrated






Photo:
Drw#2


This document and its content is the property of Airbus Defence and Space. It shall not be communicated to any third party without the owner's written consent. (Airbus Defence and Space Company name). All rights reserved.

CCA S/S: CCA CO₂ Management Section (Drw#1)

- Drw#1 includes the CO₂ Mgmt. section to observe the CO₂ quality (mass flow rate, CO₂ concentration)
- Automatic routing of CO₂ flow either to H₂/N₂ Waste GAS (CCA SA-OPS) or to Sabatier reactors (ACLS SYS-OPS).
- CO₂ supply I/F for external experiment located on Drw#1 (for the Photobioreactor).
- CO₂ flow rate range 0 – 4.5 g/min and 2.1 g/min nominal
- CO₂ 98 Vol.-%; rest water vapour and air
- p_{amb} , T approx. 35°C, T_{dew} point approx. 22°C

SA-OPS = Stand alone operation

Sys-OPS = Closed-loop system operation



CCA S/S: Air and Water Management (Drw#3)


CWSA (Condensate Water Separator Assembly)

available space for Drw#4

Air to cabin

Air Management incl.:

- CHX/CWSA
- Fan/Muffler
- Outlet Grid



CHX to reduce humidity in air released to cabin


CCA Water Management System (for Waste Water) incl.:

- UV Treatment Unit
- Gas Trap
- De-Ionisation Unit
- CFU Filter
- Water Buffer Tank




Photo: Drw#3


OGA S/S: Oxygen Generation Subsystem (Drw#6)



Drw#6 extracted from Rack



Drw#6 removed from the Rack



Drw#6 – Safety DOME opened



Photo: Drw#6



Photo: Electrolyzer Stack

CRA S/S: Carbon Dioxide Reprocessing Subsystem (Drw#4)

- Drw#4 is mechanically connected to Drw#3 but can be removed.
- Drw#4 includes two stage reactors to guarantee high hydrogen conversion (> 90%)
- High temperature for fast reaction in reactor 1 (approx. 550°C)
- Lower temperature in reactor 2 (<250°C) for high conversion
- H₂/CO₂ molar ratio 2 – 4
- Reactor operating pressure < ambient pressure to avoid leakage of reactant gases to cabin
- Water recovery (WRU): capillary condensing system without centrifugal water separator






Photo: Sabatier reactors


Performance Test results: CCA



Green curve: CCA CO2 flow to vent line or to Sabatier Reactors

Red curve: CCA CO2 Quality high with low residual O2


Performance Test results: OGA (I)



OGA: electrolyser operational parameters

This document and its content is the property of Airbus Defence and Space. It shall not be communicated to any third party without the owner's written consent ([Airbus Defence and Space Company name]). All rights reserved.


Performance Test results: OGA (I)




OGA: electrolyser cell voltage monitoring (cells 1 – 6)

This document and its content is the property of Airbus Defence and Space. It shall not be communicated to any third party without the owner's written consent ([Airbus Defence and Space Company name]). All rights reserved.

Performance Test results: CRA





CRA: Reactor temperatures



CRA: accumulated water generation

This document and its content is the property of Airbus Defence and Space. It shall not be communicated to any third party without the owner's written consent (Airbus Defence and Space Company name). All rights reserved.


I/F Test results: TCS MOD




T inlet and outlet at TCS MOD
Requirement: T outlet < 49°C

Heat Input to TCS MOD
@ Coolant flow rate approx. 150 kg/h

I/F Test results: Power Profiles



CCA in SA-OPS



OGA in SA-OPS

ACLS Operational Status	Average Main Power Bus consumption [kW]	Min. Power [kW]	Max. (Peak) Power [kW]
Stand-By (SBY)	0.25	0.2	0.3
CCA SA-OPS	0.9	0.3	3
OGA SA-OPS	1.3	1.1	2
CCA SA-OPS and OGA SA-OPS	2.0	1.2	4.1
ACLS SYS-OPS	2.1	1.2	< 4.5

This document and its content is the property of Airbus Defence and Space. It shall not be communicated to any third party without the owner's written consent ([Airbus Defence and Space Company name]). All rights reserved.

Thank you for your attention
Open questions and discussion

